

User Manual

10W Moving Head Spot Light

Model: LS10



Please read the instructions carefully before use

nichogonzo@hotmail.com

Function Instruction:

Menu		Function
Addr	A001-A512	512 Address Setup
CHnd	11CH	11channel Mode
	9CH	9channel Mode
SLnd	NASt	Master Mode
	SL 1	DMX Mode
	SL 2	Slave Mode
SHnd	SH 0	Effect option 0
	SH 1	Effect option 1
	SH 2	Effect option 2
	SH 3	Effect option 3
Soud	on	Sound control on
	oFF	Sound control off
SEnS	0-99	Sound Sensitivity Adjustment
bLnd	bLAc	No 512 signal zero
	Auto	No 512 signal Auto
	Soun	No 512 signal Sound
	Hold	No 512 signal Keep the last state control
LEd	OFF	Black light off
	ON	Black light on
DISP	no	Forward direction show
	YES	Inversion direction show
rPAN	no	X Motor Turn
	YES	X Motor Inversion
rTiL	no	Y Motor Turn
	YES	Y Motor Inversion
REST	YES	System Reset

11 Channel mode:

CH	Function	Value	Function
1	X Axis	0-255	0~540°
2	X Axis fine tuning	0-255	16bit adjustable
3	Y Axis	0-255	
4	Y Axis fine tuning	0-255	16bit adjustable
5	Color	0 - 9	White
		10 - 19	Orange
		20 - 29	Light blue
		30 - 39	Red
		40 - 49	Green
		50 - 59	Blue
		60 - 69	Yellow
		70 - 79	Violet
		80 - 89	Violet - Yellow
		90 - 99	Yellow - Blue
		100 - 109	Blue - Green
		110 - 119	Green - Red
		120 - 129	Red - Light Blue
		130 - 139	Light Blue - Orange
		140-255	Color change from slow to fast

11 Chanel mode:

6	Gobos	0 - 7	Gobo 1
		8 -15	Gobo 2
		16 - 23	Gobo 3
		24 - 31	Gobo 4
		32 - 39	Gobo 5
		40 - 47	Gobo 6
		48 - 55	Gobo 7
		56 - 71	Gobo 8
		72 - 79	Gobo Shake 1
		80 - 87	Gobo Shake 2
		88 -95	Gobo Shake 3
		96 - 103	Gobo Shake 4
		104 - 111	Gobo Shake 5
		112 - 119	Gobo Shake 6
		120 - 127	Gobo Shake 7
		128 - 255	Gobo Change from slow to fast
7	Strobe	0 - 255	Non-Function Slow to fast
8	Master Dimmer	0 - 255	Linear dimming from dark to bright
9	X/Y Motor Speed	0 - 255	From fast to Slow
10	General	0 - 59	No fuction
		60 - 84	Auto Mode 3
		85 - 109	Auto Mode 2
		110 - 134	Auto Mode 1
		135 - 159	Auto Mode 0
		160 - 184	Sound Mode 3
		185 - 209	Sound Mode 2
		210 - 234	Sound Mode 1
		235 - 255	Sound Mode 0
11	Reset	0 - 255	Reset

9 Channel Mode:

CH	Function	Value	Function
1	X Axis	0-255	0~540°
2	Y Axis	0-255	
3	Color	0-139	Color choose
		140-255	Color change from slow to fast
4	Gobo	0-63	Gobo choose
		64-127	Gobo shake
		128-255	Gobo change from slow to fast
5	strobe	0-255	non-function slow to fast
6	Master dimmer	0-255	Linear dimming from dark to bright
7	X/Y motor effect & speed	0-255	From fast to slow
8	Auto Mode	0-255	From fast to slow
9	Reset	0-255	

Specification:

Light source: 1*10W white LED

Power supply: 100-240V/50-60HZ Rated power: 35W

Control Mode: Auto/Sound/DMX/Master-slave

Channels: 9/11 Gobo: 7+open Color: 7+open

Scanning: Pan 540° Tilt 270°

N.W/G.W.: 2.7KG/3.5KG

Size: 160*150*225mm